



Agriculture and Markets

10B Airline Drive, Albany, New York 12235
1-800-554-4501
www.agriculture.ny.gov

Bureau of Weights and Measures
518-457-3452
FAX: 518-457-2552

Wheel-Load Weigher Report of Test

Test No: W20-027

Issued: 04/02/2020

For: NYS Police Traffic Section, Troop D
Building 22, State Campus
Albany, NY 12226

The scales listed below have been compared to standards of New York State which are traceable to the National Institute of Standards and Technology. Tolerances are 2% of applied test load. Scale sets are tested as a pair and must be used as such. Note: An * in Status field indicates security seals from previous test were broken.

Set	DD15	Scale Mfr/Model: Haenni / WL101	Indicator Mfr/Model: N/A / N/A	Serial Nos: 19890 & 19891	Serial No: N/A	
	Tested	03/30/2020 - 9:12	Status: Pass			
	Load/Reading	9124 / 9125	19468 / 19425	29306 / 29275	39267 / 39200	Test: p
Set	DD16	Scale Mfr/Model: Haenni / WL101	Indicator Mfr/Model: N/A / N/A	Serial Nos: 19892 & 19893	Serial No: N/A	
	Tested	03/27/2020 - 13:03	Status: Pass			
	Load/Reading	9498 / 9475	18692 / 18650	28750 / 28875	38470 / 38700	Test: p
Set	DD17	Scale Mfr/Model: Haenni / WL101	Indicator Mfr/Model: N/A / N/A	Serial Nos: 19894 & 19895	Serial No: N/A	
	Tested	03/27/2020 - 12:55	Status: Pass			
	Load/Reading	9146 / 9150	19106 / 19125	28979 / 28975	38794 / 38750	Test: p
Set	DD19	Scale Mfr/Model: Haenni / WL101	Indicator Mfr/Model: N/A / N/A	Serial Nos: 21559 & 21560	Serial No: N/A	
	Tested	03/25/2020 - 12:48	Status: Pass			
	Load/Reading	8922 / 8800	19006 / 18725	29459 / 29075	39491 / 39050	Test: p
Set	DD20	Scale Mfr/Model: Haenni / WL101	Indicator Mfr/Model: N/A / N/A	Serial Nos: 21561 & 21562	Serial No: N/A	
	Tested	03/25/2020 - 12:40	Status: Pass			
	Load/Reading	9412 / 9425	18430 / 18550	28616 / 28850	38582 / 38725	Test: p
Set	DD21	Scale Mfr/Model: Haenni / WL101	Indicator Mfr/Model: N/A / N/A	Serial Nos: 21563 & 21564	Serial No: N/A	
	Tested	03/26/2020 - 9:37	Status: Pass			
	Load/Reading	8557 / 8625	18963 / 19025	28699 / 28825	38451 / 38550	Test: p

Set	DD22	Scale Mfr/Model: Haenni / WL101	Serial Nos: 21565 & 21566			
		Indicator Mfr/Model: N/A / N/A	Serial No: N/A			
	Tested	03/25/2020 - 12:20	Status: Pass			
		Load/Reading	9039 / 9050	18804 / 18925	28732 / 29025	38665 / 38950
						Test: p
Set	DD23	Scale Mfr/Model: Haenni / WL101	Serial Nos: 21567 & 21568			
		Indicator Mfr/Model: N/A / N/A	Serial No: N/A			
	Tested	03/26/2020 - 9:20	Status: Pass			
		Load/Reading	8625 / 8700	19002 / 19225	28753 / 29100	38449 / 38975
						Test: p
Set	DD26	Scale Mfr/Model: Haenni / WL101	Serial Nos: 21573 & 21574			
		Indicator Mfr/Model: N/A / N/A	Serial No: N/A			
	Tested	03/25/2020 - 13:57	Status: Pass			
		Load/Reading	9119 / 9125	18981 / 18975	28932 / 28950	38184 / 38225
						Test: p
Set	DD28	Scale Mfr/Model: Haenni / W101	Serial Nos: 27256 & 27257			
		Indicator Mfr/Model:	Serial No:			
	Tested	03/27/2020 - 12:45	Status: Pass			
		Load/Reading	9097 / 9175	19257 / 19375	28420 / 28625	38854 / 38900
						Test: p
Set	DD29	Scale Mfr/Model: Haenni / W101	Serial Nos: 27258 & 27259			
		Indicator Mfr/Model:	Serial No:			
	Tested	03/25/2020 - 13:50	Status: Pass			
		Load/Reading	8891 / 8975	18951 / 19050	28622 / 28825	38773 / 38975
						Test: p
Set	DD30	Scale Mfr/Model: Haenni / WL101	Serial Nos: 28874 & 28875			
		Indicator Mfr/Model: N/A / N/A	Serial No:			
	Tested	03/26/2020 - 9:05	Status: Pass			
		Load/Reading	9107 / 9100	19018 / 19100	28932 / 28900	38932 / 39025
						Test: p
Set	DD31	Scale Mfr/Model: Haenni / WL101	Serial Nos: 30180 & 30181			
		Indicator Mfr/Model: N/A / N/A	Serial No:			
	Tested	03/30/2020 - 9:27	Status: Pass			
		Load/Reading	8866 / 8975	18825 / 18950	29004 / 29275	38219 / 38700
						Test: p
Set	DD32	Scale Mfr/Model: Haenni / WL101	Serial Nos: 30182 & 30183			
		Indicator Mfr/Model: N/A / N/A	Serial No:			
	Tested	03/25/2020 - 12:05	Status: Pass			
		Load/Reading	8891 / 9050	18632 / 18825	28659 / 28900	38572 / 38900
						Test: p
Set	DD33	Scale Mfr/Model: Haenni / WL101	Serial Nos: 30185 & 30186			
		Indicator Mfr/Model: N/A / N/A	Serial No:			
	Tested	03/26/2020 - 9:12	Status: Pass			
		Load/Reading	8767 / 8825	19000 / 19075	28877 / 28975	38853 / 39025
						Test: p
Set	DD34	Scale Mfr/Model: Haenni / WL101	Serial Nos: 30187 & 30188			
		Indicator Mfr/Model: N/A / N/A	Serial No:			
	Tested	03/26/2020 - 8:58	Status: Pass			
		Load/Reading	9379 / 9200	19165 / 18825	29491 / 29000	39422 / 39075
						Test: p
Set	DD35	Scale Mfr/Model: Haenni / WL101	Serial Nos: 31473 & 31474			
		Indicator Mfr/Model: N/A / N/A	Serial No:			
	Tested	03/25/2020 - 13:02	Status: Pass			
		Load/Reading	8510 / 8550	18581 / 18600	28458 / 28500	38623 / 38750
						Test: p

Set DD36	Scale Mfr/Model: Haenni / WL101	Serial Nos: 31471 & 31472
	Indicator Mfr/Model: N/A / N/A	Serial No:
Tested	03/25/2020 - 13:20 Status: Pass	
	Load/Reading 8672 / 8750 18706 / 19025	28654 / 29050 38685 / 39125 Test: p
Set DD37	Scale Mfr/Model: Haenni / WL101	Serial Nos: 31469 & 31470
	Indicator Mfr/Model: N/A / N/A	Serial No:
Tested	03/25/2020 - 12:27 Status: Pass	
	Load/Reading 8710 / 8825 18653 / 18775	29291 / 29450 39015 / 39225 Test: p
Set DD38	Scale Mfr/Model: Haenni / WL101	Serial Nos: 32252 & 32253
	Indicator Mfr/Model: N/A / N/A	Serial No:
Tested	03/26/2020 - 9:28 Status: Pass	
	Load/Reading 8926 / 8925 18998 / 18975	28830 / 28850 38638 / 38675 Test: p
Set DD39	Scale Mfr/Model: Haenni / WL101	Serial Nos: 32254 & 32255
	Indicator Mfr/Model: N/A / N/A	Serial No:
Tested	03/25/2020 - 13:11 Status: Pass	
	Load/Reading 8911 / 9000 18902 / 18975	28857 / 28875 38717 / 38675 Test: p
Set DD40	Scale Mfr/Model: Haenni / WL101	Serial Nos: 32256 & 32257
	Indicator Mfr/Model: N/A / N/A	Serial No:
Tested	03/30/2020 - 8:59 Status: Pass	
	Load/Reading 8844 / 8875 19219 / 19300	29245 / 29450 38431 / 38700 Test: p
Set DD41	Scale Mfr/Model: Haenni / WL101	Serial Nos: 33443 & 33444
	Indicator Mfr/Model: N/A / N/A	Serial No:
Tested	03/25/2020 - 13:44 Status: Pass	
	Load/Reading 9129 / 9175 18841 / 18800	28654 / 28575 38805 / 38800 Test: p
Set DD42	Scale Mfr/Model: Haenni / WL101	Serial Nos: 38250 & 38251
	Indicator Mfr/Model: N/A / N/A	Serial No:
Tested	03/25/2020 - 12:55 Status: Pass	
	Load/Reading 8934 / 9025 18336 / 18475	28790 / 28925 39398 / 39500 Test: p
Set DD43	Scale Mfr/Model: Haenni / WL101	Serial Nos: 38714 & 38715
	Indicator Mfr/Model: N/A / N/A	Serial No:
Tested	03/25/2020 - 12:12 Status: Pass	
	Load/Reading 8559 / 8700 18451 / 18475	28486 / 28650 38574 / 38875 Test: p
Set DD44	Scale Mfr/Model: Haenni / WL101	Serial Nos: 39188 & 39189
	Indicator Mfr/Model: N/A / N/A	Serial No: N/A
Tested	03/25/2020 - 12:33 Status: Pass	
	Load/Reading 9078 / 9100 18688 / 18825	29005 / 28975 38932 / 38925 Test: p
Set DD45	Scale Mfr/Model: Haenni / WL101	Serial Nos: 39190 & 39191
	Indicator Mfr/Model: N/A / N/A	Serial No: N/A
Tested	03/25/2020 - 13:28 Status: Pass	
	Load/Reading 8955 / 8950 18859 / 18725	28425 / 28450 39109 / 39075 Test: p
Set DD46	Scale Mfr/Model: Haenni / WL101	Serial Nos: 39192 & 39193
	Indicator Mfr/Model: N/A / N/A	Serial No: N/A
Tested	03/25/2020 - 13:36 Status: Pass	
	Load/Reading 8594 / 8675 19061 / 19125	28594 / 28625 39018 / 39025 Test: p

Set DD47	Scale Mfr/Model: Haenni / WL101	Serial Nos: 39755 & 39756
	Indicator Mfr/Model: N/A / N/A	Serial No: n/a
Tested	03/25/2020 - 11:55	Status: Pass
	Load/Reading	8961 / 9000 19021 / 19025 28432 / 28600 38999 / 39050 Test: p
Set DD48	Scale Mfr/Model: Haenni / WL101	Serial Nos: 39757 & 39758
	Indicator Mfr/Model: N/A / N/A	Serial No: n/a
Tested	03/25/2020 - 12:00	Status: Pass
	Load/Reading	8866 / 8925 19249 / 19275 28646 / 28725 38962 / 39050 Test: p
Set DDD2	Scale Mfr/Model: Intercomp / AX900	Serial Nos: 13001/13003 & 13002/13004
	Indicator Mfr/Model: Intercomp / PT-20	Serial No: 12181F13001
Tested	03/23/2020 - 13:49	Status: Pass
L1	Load/Reading	5000 / 5000 10000 / 10000 15000 / 15050 20000 / 20050 Test: p
L1a	Load/Reading	25000 / 25050 30000 / 30050 Test: p
L2	Load/Reading	5000 / 5000 10000 / 10050 15000 / 15050 20000 / 20000 Test: p
L2a	Load/Reading	25000 / 25000 30000 / 29900 Test: p
R1	Load/Reading	5000 / 5000 10000 / 10000 15000 / 15000 20000 / 20000 Test: p
R1a	Load/Reading	25000 / 25000 30000 / 30000 Test: p
R2	Load/Reading	5000 / 5000 10000 / 10000 15000 / 15000 20000 / 20000 Test: p
R2a	Load/Reading	25000 / 25050 30000 / 30050 Test: p

Weights and Measures Officials

David J. Fiegel
Mark J. Fiegel

Enforcement Officials

Timothy J. Gorman #5079